

TIMEWASH® TIMER

- Encourages proper hand-washing procedures
- Easily activated by a wave of the hand

This countdown TimeWash timer is designed for use in restaurants, hospitals, schools and in any businesses where hand hygiene is critical. The unit is easy to install and can be mounted on a wall near the sink using Velcro (supplied) or double-sided tape.

The TimeWash timer is easily activated by a wave of the hand that starts the countdown timer. The large clear LCD acts as a visual progress monitor, and when the time is complete the user will hear a loud audible alarm indicating that their hand wash is complete. Incorporating eight pre-set countdown times, 20, 30 and 40 seconds, 1, 2, 3, 4 and 10 minutes, the set time button is discreetly positioned on the rear of the unit.

The TimeWash timer is a great tool to encourage employees to take the time to properly wash their hands by giving them a visual cue.



Order code	Description
806-201	TimeWash timer

Specification	TimeWash Timer
Range (pre-set)	20, 30 and 40 seconds, 1, 2, 3, 4 and 10 minutes
Resolution	Seconds & Minutes
Accuracy	1% FS
Battery	2 x 1.5 volt AAA
Battery life	3 months
Display	Custom LCD
Dimensions	20 x 91 x 101 mm
Weight	130 grams

TIMESTICK® TIMER



The TimeStick is a handy-sized, portable timer with a water resistant numeric keypad. The countdown bar graph gives you a quick indicator of remaining time. When the countdown alarm sounds, the count up timer starts to show how much time has elapsed since activating the alarm.

The TimeStick also features a 12 or 24 hour format, keypad lock to prevent accidental key entry and is powered by a CR2032 battery.

Order code	Description	
806-181	TimeStick timer - white	4099679
806-184	TimeStick timer - red	
806-185	TimeStick timer - blue	

THREE CHANNEL TIMER



This countdown/up timer with clock and 80 dB loud audible alarm, is fully programmable allowing the user to preset and view up to three different alarm times simultaneously.

When you set a countdown time, the start/stop button starts the timer. When the alarm sounds, a count up starts so you know how long since the alarm sounded. Pause and continue any timer at any time.

The unit is powered by 2 x AAA batteries and is designed to sit on a worktop or be attached to an appliance via the magnetic pads to the rear of the instrument.

Order code	Description	
806-301	Three channel timer	4099682